


Jabra Elite Active 75t Wireless Charging - Grey

How do I turn on/off my Jabra Elite 75t/Elite Active 75t?

To turn on your Jabra Elite 75t/Elite Active 75t, remove the earbuds from the charging case. To turn off the earbuds, place them in the charging case.

Alternatively, to manually turn on the earbuds, simultaneously press and hold (2 seconds) the **Left** and **Right** buttons. The earbuds will flash green to indicate they have been turned on. To turn off the earbuds, simultaneously press and release the **Left** and **Right** buttons. The earbuds will flash red to indicate they have been turned off.



Note

Images are for guidance purposes only. The displayed image may differ slightly from your device, however the content is still relevant and accurate.