

Jabra Evolve 30 II MS Stereo

How do I use my Microsoft Teams certified device to interact with Microsoft Teams?

Prerequisites

- Connection to a Jabra MS variant that is certified for use with Microsoft Teams
- [Microsoft Teams for computers](#)

When you are connected to your Jabra device and you sign into Microsoft Teams, you can interact with Microsoft Teams on your computer in the following ways.

- If the Microsoft Teams window is minimized, press the **Multi-function** button on the controller to bring the window to the foreground on your computer.
- A Microsoft Teams LED notification will flash on the controller when a scheduled Microsoft Teams meeting becomes active (when another participant joins the meeting). Press the **Multi-function** button on the controller to join the active meeting on your computer.
- A Microsoft Teams LED notification will flash on the controller if you have missed a Microsoft Teams call. Press the **Multi-function** button on the controller to see the notification in Microsoft Teams under **Calls, History**.
- A Microsoft Teams LED notification will flash on the controller if there is a Microsoft Teams voicemail. Press the **Multi-function** button on the controller to see the notification in Microsoft Teams under **Calls, Voicemail**.

Note

The Microsoft Teams LED notifications will flash in response to only one Microsoft Teams notification at a time. Pressing the **Multi-function**

button will interact with the last received notification.

Applicable products



**Jabra Evolve 40 Link
MS USB-C**



**Jabra Evolve 40 Link
MS**



**Jabra Evolve80 Link
MS**



**Jabra Evolve 80 Link
MS USB-C**



**Jabra Biz 2300 USB
MS Mono**



**Jabra Biz 2300 USB
MS Duo**



**Jabra Biz 2300 USB-C
MS Mono**



**Jabra Biz 2300 USB-C
MS Duo**



**Jabra Engage 40 -
(Inline Link) USB-C**



**Jabra Engage 40 -
(Inline Link) USB-C**



**Jabra Evolve 80 MS
Stereo**



**Jabra Evolve 80 MS
Stereo USB-C**



**Jabra Evolve 40 MS
Mono**



**Jabra Evolve 40 MS
Stereo**



**Jabra Evolve 40 MS
Mono USB-C**



**Jabra Evolve 40 MS
Stereo USB-C**



**Jabra Engage 40 -
(Inline Link) USB-A**



**Jabra Engage 40 -
(Inline Link) USB-A**



**Jabra Engage 50 II -
(Engage 50 II Link)**



**Jabra Engage 50 II -
(Engage 50 II Link)**



**Jabra Engage 50 II -
(Engage 50 II Link)**



**Jabra Engage 50 II -
(Engage 50 II Link)**



**Jabra Biz 2400 II USB
Duo CC MS**



**Jabra Biz 2400 II USB
Mono CC MS**



**Jabra Evolve 20 -
USB-C, MS Stereo**



**Jabra Evolve 20 -
USB-C, MS Mono**



**Jabra Evolve 20 MS
Stereo**



**Jabra Evolve 20 MS
Mono**



**Jabra Evolve 30 II MS
Stereo**



**Jabra Evolve 30 II MS
Mono**



**Jabra Evolve 30 MS
Mono**



**Jabra Evolve 30 MS
Stereo**



Jabra Evolve 30 II
USB-C MS Mono

Jabra Evolve 30 II
USB-C MS Stereo